

# 1400 SERIES/1500 SERIES ELECTRIC DECK OVEN REPLACEMENT PARTS LIST



### **EFFECTIVE JULY 6, 2004**

**BLODGETT OVEN COMPANY**, 44 Lakeside Avenue, Burlington, Vermont 05401 USA Telephone: (802) 860-3700 (800) 331-5842 Fax: (802) 860-3732 www.blodgett.com

IMPORTANT: When ordering parts, please provide the model, gas type and serial number of the oven. The identification plate is located on the left side of the combustion compartment and, also, above the control panel under the ledge.

**1400 SERIES** 

September 12, 2002

ASAP Distributor Required Stocking Parts

♦ Doors Are Not Returnable

Daf

#### 2

#### **ELECTRICAL COMPONENTS**

Ref. <u>No.</u>	Part <u>No.</u>	<u>Description</u>
1	20537	Element Assy., Bottom 208V
1	20538	Element Assy., Bottom 240V
2	19822	Element Assy., Middle 208V
2	19938	Element Assy., Middle 220/240V
	20539	Element Assy., Top 208V
	20540	Element Assy., Top 240V
3	38091	Receptacle, Center Element

#### **MECHANICAL CONTROLS**

Ref.	Part	
No.	No.	Description
30 ☑	15956	Timer, 60 Minute
	16686	Knob, Timer
31	21554	Buzzer, Timer 240V
28	20546	Thermostat w/ Terminal, Mechanical
22	16686	Knob, Thermostat
27	18353	Terminal Adapter, Thermostat
6	19619	Rocker Switch, DPST, Black
29	20436	Indicator Light, 250V, Clear, Rectangular
	20547	Contactor, 35 Amp.
	18836	Contactor, Mercury, 30 Amp., 3 Pole
		(For Solid State Thermostat)
	17556	Terminal Block, 90 Amp., 3 Pole
	23086	Suppressor Assy., RC
$\checkmark$	1 21430	Axial Fan, 230V, 34 CFM, 3"
	M1376	Guard, Axial Fan
24	21553	Cable Assy., Strain Relief
23	20541	Panel Assy., Control
25	20542	Hinge Assy., Control Panel
26	20543	Control Panel & Decal, Mechanical
	20544	Thermostat/Mechanical Timer Control Panel & Decal, Mechanical Thermostat/Solid State Timer
	20551	Transformer for Timer

#### **SOLID STATE INFINITE CONTROL**

	Ref No.	-	Part <u>No.</u>	<u>Description</u>
	50		18578	Control, Temperature
		$   \sqrt{} $	18588	Probe, Temperature
	34	$\checkmark$	18234	Potentiometer, Remote
	41		16037	Light, Ind. 250V Red, Round
	48	$\checkmark$	18226	Timer, 60 Minute 240V
	6	$\checkmark$	19619	Switch, Rocker DPST, Black
			5634	Buzzer, 240V
		$\checkmark$	18836	Contactor, HG 3Pole 30 AMP
t			33517	Harness, Control
			15934	Knob, Time & Temp Control
			33530	Infinite Control Module (To change
				controls)
			19751	Clip, Bulb Thermistor
	22		16686	Knob, Control
l	47		18268	Nylon Spacer
l	7		20541	Control Panel Assy.
l			32297	Spacer, Circuit Board
			33502	Decal, Control (Cracker Barrel)
				·

#### **SOLID STATE DIGITAL CONTROLS**

(Current Style with 2 or 3 Button Decal)

Ref.	Part	
<u>No.</u>	<u>No.</u>	<u>Description</u>
5	32472	Controller w/ 2 Button Decal (Includes the Panel & Decal Assy.) (See Note)
8	24181	Knob, Control
✓	1 23392	Probe, Temperature RTD
6	19619	Rocker Switch, DPST, Black
4	21553	Cable Assy., Strain Relief
7	20541	Panel Assy., Control
	24193	Wiring Harness, Solid State Control Module
5	32472	Control Panel & Decal Assy.
		(For 3 Button to 2 Button Decal Conversion) (Includes the Controller)
9	31192	Decal Only (For 2 Button)

NOTE: If you do not have a 32472 in stock, you can use the the 24448 conversion kit in its place. If you need to order the control panel & decal with 3 buttons, you must order 32472 to convert it to the current 2 button decal. The decal only (p/n 31192) is available for ovens with the current 2 button decal already.

#### **SOLID STATE CONTROLS**

(Old Style with 12 Button Decal)

Ref. <u>No.</u>	Part <u>No.</u>	<u>Description</u>
	24448	Conversion Kit, 12 Button to Current Control with 2 Button Decal
		(Complete Module Assy.) (See Note)
22	16686	Knob, Control
35	20549	Controller, Temperature RTD
36	19735	Probe, Temperature Controller RTD
34 ☑	18234	Potentiometer, Remote
21	19619	Rocker Switch, DPST, Black
29	20436	Indicator Light, 250V, Clear, Rectangular
24	21553	Cable Assy., Strain Relief
7	20541	Panel Assy., Control
	24193	Wiring Harness, Solid State Control Module


NOTE: If you need either the timer or the control panel and decal assy. for the 12 button control, you need to order part number 24448 conversion kit to the current control with 2 button decal.


#### **INTERIOR COMPONENTS**


Ref. <u>No.</u>	Part <u>No.</u>	<u>Description</u>				
	19955 31144	Deck, Steel Deck, Cordierite (3/4" x 19-1/2" x 19-1/2")				


#### **EXTERIOR COMPONENTS**

Ref. <u>No.</u>	Part <u>No.</u>	Description
	20095	Door Assy., S/S, Drop Down (After 2/10/89)
	19986	Door Assy., Solid, Roll-Up (After 2/10/89)
	20928	Door Kit, Roll-Up w/o Middle Element (Before 2/10/89)
	20929	Door Kit, Roll-Up w/ 208V Middle Element (Before 2/10/89)
	20930	Door Kit, Roll-Up w/ 220V Middle Element (Before 2/10/89)
	20931	Door Kit, Roll-Up w/ 240V Middle Element (Before 2/10/89)
	21550	Arm Assy., Door LH Roll-Up
	21551	Arm Assy., Door RH Roll-Up
	21556	Brackets, Door Arm Roll-Up
	20139	Bearing, Door Roll-Up (Set of 2)
	21552	Hinge Pin, Door Roll-Up (Set of 2)
	19807	Crumb Tray Assy., Roll-Up
	20734	Microswitch Assy., Door Roll-Up
	20146	Cam Assy., Door Roll-Up
	21528	Bearing, Door Drop-Down (Set of 2)
	17559	Bushing, Roll-Up
	21527	Hinge Pin, Door Drop-Down (Set of 2)
	23009	Handle, Door Conversion Kit (Before 11/15/91)
	20140	Handle, Door (w/rod), (After 11/15/91)
	35184	Window Bracket (L & R) (for handles) (For units after 11/15/91)
	**NOTE	This Kit 35184 replaces 20533 & 20534 single brackets.
	20527	Catch, Door (Pressure Latch)
	20526	Catch, Door (Striker Plate)
	20535	Gasket, Top Door S/S
	19556	Nameplate, Blodgett 4"
	20557	Back Panel, Louvered
	20536	Body Top & Sides, S/S
	21109	Stacking Kit, 1400 on 1400
	20435	Legs, 4" Painted (Set of 4)
	24934	Stand, 19" S/S w/ Casters
	32298	Heat Shield (1405/1415)










IMPORTANT: When ordering parts, please provide the model, gas type and serial number of the oven. The identification plate is located on the left side of the combustion compartment and, also, above the control panel under the ledge.

## **1500 SERIES**


July 6, 2004

 $\checkmark$ **ASAP Distributor Required Stocking Parts** 

**Doors Are Not Returnable** 



6



ELECTRICAL COMPONENTS	EXTERIOR

1 20470 Thermostat 2 20471 Knob, Thermostat 3 19619 Switch, Rocker DPST Black 4 20469 Thermometer 5 20472 Indicator Light, Red, Round, 250V 6 20475 Element Assy., Top, 115V, 75 Watt 7 20478 Element Assy., Bottom, 115V, 250 Watt 8 20480 Lamp, 120V, 40 Watt 9 20481 Socket, Lamp Single 10 20482 Socket, Lamp Twin 11 20477 Cord Set Assy., 120V, 15 AMP		art lo.	<u>Description</u>	Ref. <u>No.</u>		Part <u>No.</u>	<u>Description</u>
8 20480 Lamp, 120V, 40 Watt 18 20473 Decal, Power Tag 9 20481 Socket, Lamp Single 10 20482 Socket, Lamp Twin	2 20 3 19 4 20 5 20 6 20	0471 9619 0469 0472 0475	Knob, Thermostat Switch, Rocker DPST Black Thermometer Indicator Light, Red, Round, 250V Element Assy., Top, 115V, 75 Watt	13 14 15	<b>*</b>	20468 20474 20476 20558 20479	Door Assy., Right Hinge Glass Assy., Front (1501 Only) Glass Assy., End Welded Glass Assy., End (Old Style) (4 Req'd) Catch, Door
2017 3014 3017 10711111	8 20 9 20 10 20	0480 0481 0482	Lamp, 120V, 40 Watt Socket, Lamp Single				• • • • • • • • • • • • • • • • • • • •